
Section Views








Sectioning image





NO information about apple inside











After cutting we get information about in side





NO information about inside Watermelon





Cutting the watermelon by knife







PURPOSES OF SECTION VIEWS

- Clarify the views by
 - reducing or eliminating the hidden lines.
 - revealing the cross sectional's shape.
- Facilitate the dimensioning.

Let See the example




Terminology and common practices




CUTTING PLANE

Cutting plane is a plane that imaginarily cuts the object to reveal the internal features.




CUTTING PLANE LINE


Cutting plane line is an edge view of the cutting plane.



CUTTING PLANE LINESTYLES



Kinds of Sections





KIND OF SECTIONS


- 1. Full section
- 2. Offset section
- 3. Half section
- 4. Broken-out section

FULL SECTION VIEW


The view is made by passing the *straight* cutting plane *completely through* the part.










- When the cutting plane passes through Thin features, such as RIB or a WEB, Shafts, Keys & Splines, Nuts, Bolts & Rivets.
- 2. Such Parts are not sectioned.



Views obtained by "offsetting" or bending the cutting plane.
are called an OFFSET SECTIONAL VIEWS.









OFFSET SECTION VIEW

The view is made by passing the *bended* cutting plane *completely through* the part.




- Several features of an object that do not lie in a straight line,
- Such features can be shown by "offsetting" or bending the cutting plane.
- The section is then called an OFFSET SECTION.




TREATMENT OF HIDDEN LINES

Hidden lines are *normally omitted* from section views.




HALF SECTION VIEW

The view is made by passing the cutting plane *halfway* through an object and remove a *quarter* of it.




HALF SECTION VIEW


- A *center line* is used to separate the sectioned half from the unsectioned half of the view.
- Hidden line is omitted in unsection half of the view.




EXAMPLE: Comparison among several section techniques




Intersection of objects



Rectangle and Circle





circle and Circle

